


Cartridge Priming Clip Instructions

INSTRUCTIONS

1. Slightly dab the printhead with a moist towelette or paper towel to ensure proper adhesion to the clip.



2. Insert the cartridge by tensioning the top rear tab of the clip and clicking it into position. This process may be tight and require some force.



3. Insert the syringe into the designated hole on the bottom of the cartridge clip.



4. Slightly pull the syringe toward you. There should be some resistance due to the seal between the cartridge and the clip. If you do not feel any resistance, re-mount the cartridge. Pull the syringe further to draw about 1 mL of ink to complete the priming process.



5. Dab the printhead again with a moist towelette or paper towel to ensure a clean printhead. Insert the cartridge back into the printer again and follow your printer's cleaning procedure. Print a test page to determine if the cartridge is working properly.



TROUBLESHOOTING

If you are having trouble with your priming clip or would like to contact us about a general issue, open a support ticket at support.hyrastrading.com or email us at support@hyrastrading.com

Please allow up to 1 business day for a reply. We are open from Monday-Friday.